

# Read Me First

## for the ProCurve 408 Switch

---

### Contents

About Your ProCurve 408 Switch Manual Set ..... [page 1](#)  
 DC Voltage Rating ..... [page 1](#)  
 View or Download the Software Manual Set ..... [page 2](#)  
 Your *Free* Introduction to Proactive Networking! ..... [page 2](#)  
 Software Updates Are *Free!* ..... [page 3](#)

---

### About Your ProCurve Series 408 Switch Manual Set

The switch manual set includes the following:

Document	Available on the ProCurve web site	Shipped With the Switch
<i>Read Me First</i> (this document) <sup>1</sup>	Yes	Yes
<i>Installation Guide</i> <sup>1</sup>	Yes	Yes

<sup>1</sup>The latest edition is always available in PDF format and downloadable as described in [“View or Download the Software Manual Set”](#) on page 2.

---

### DC Voltage Rating

The ProCurve Switch 408 (J4097C) has a nominal DC voltage rating of 13 volts, as displayed on the back panel on the switch. The power adapter provided with this ProCurve Switch 408 has a DC voltage rating of 12 volts. This power adapter has been fully certified. The ProCurve Switch 408 will operate safely and reliably with this 12 volt power adapter.

The operational specifications for the power adapter are:

- The operating ambient temperature should not exceed 40°C (104°F).
- The maximum altitude should not exceed 3.0 km (9,843 ft).

### Power Adapters

Listed below are the applicable power adapters:

#### Region Adapter / Part Number

Universal Adapter / 5188-6700\*

Australia/New Zealand / 5188-5678

China / 5188-5677

Denmark/Switzerland / 5188-5673

Europe/Russia / 5188-5673

Japan / 5188-5676

United Kingdom/Hong Kong/Singapore / 5188-5672

United States/Canada/Taiwan / 5188-5671

\* A country-specific power cord is shipped with this adapter.

---

## View or Download the Software Manual Set

The printed *Installation Guide* shipped with your ProCurve product describes installing, minimally configuring, and troubleshooting. For further software feature and configuration information, visit the ProCurve Web site, where you can freely view or download the latest software manuals for your product. To do so, go to:

[www.procurve.com/manuals](http://www.procurve.com/manuals)

You may want to bookmark this Web page for easy access in the future.

You can also register on the My ProCurve portal to receive a set of ProCurve switch manuals on CD-ROM. To register and request a CD go to [www.procurve.com](http://www.procurve.com) and click on **My ProCurve Sign In**. After registering and entering the portal, click on **My Manuals**.

---

## Your Free Introduction to Proactive Networking!

ProCurve Manager and ProCurve Manager Plus offer a breakthrough in network management software that gives you more network with less work. ProCurve Manager and a 30-day trial of ProCurve Manager Plus are available for free on the ProCurve Networking Web site. Also available on the ProCurve Web site are 30-day free trials of Mobility Manager, Identity-Driven Manager, and Network Immunity Manager. To download any of these options, visit [www.procurve.com/software](http://www.procurve.com/software) and click on **Network management**.

---

## Software Updates Are *Free!*



ProCurve Networking provides free software updates on the ProCurve Web site for your switch. To access the software updates, go to the ProCurve Web site at [www.procurve.com/software](http://www.procurve.com/software), then click on **Switches** to go to the page that has the free download for your switch.

**Register for Automatic Notification of Updates.** You can receive email notices of new software updates by registering your ProCurve product on the ProCurve Web portal. To begin this easy process, go to [www.procurve.com](http://www.procurve.com) and click on **My ProCurve Sign In**.

To determine whether you have the latest software, you can compare the software version that is available on the web site with the version that is currently installed on your switch. Follow the instructions below to determine the current software version on your switch.

**To Determine the Current Software Version in Your Switch.** Use any of the following methods to view the software version:

- Start a console session with the switch. In the console login screen (the first screen displayed), the **Software revision** line under the switch name shows the software version.
- If you already have a console session going, at the prompt enter the **show version** command. The resulting display lists the current software version.
- In the web browser interface, click on the **Identity** tab. The current software version is listed as the **revision** number in the **Version** line.

© Copyright 2007-2008 Hewlett-Packard  
Development Company, L.P.  
The information contained herein  
is subject to change without notice.



Part Number: 5992-4937  
June 2008  
Printed in Taiwan

