

Replacing the 6600 Series Fan Tray Assembly

When a fan fails the Fan Status LED on the switch chassis will blink simultaneously with the switch Fault LED. In this case, the entire fan tray assembly needs to be replaced. Individual fans cannot be replaced.

The fan tray assembly is hot swappable. It can be removed and replaced without removing power from the switch. However, install the new fan tray assembly immediately (within two minutes) after

To replace a fan tray assembly:

1. Unscrew the retaining screws
2. Holding the two retaining screws, pull the fan tray assembly straight out.
3. Remove the new fan tray assembly from its packaging.
4. Holding the new fan tray assembly by the two retaining screws, insert the new fan tray assembly fully. The face plate of the fan tray will be flush with the back face of the switch.
5. Engage the retaining screws and tighten. Be sure to not over tighten the screws.

