
Read Me First

for ProCurve Manager 3.0, Identity Driven Manager 3.0, Mobility Manager 3.0, Network Immunity Manager 2.0

Open the **install.exe** file to install PCM software downloaded from **www.procurve.com/networkmanagement**. If installing PCM from a CD, insert the product CD into the CD ROM drive in the computer you will use as the network management station. If the wizard doesn't open automatically, double-click the **install.exe** file.

PCM is used below to refer to both the ProCurve Manager and ProCurve Manager Plus software.

Before you Install

Please refer to the *ProCurve Management v3 Release Notes* for the latest information. The latest PCM documentation can be accessed at:

www.procurve.com/pcm-manuals

UPGRADE NOTE:

Once you upgrade to PCM 3.0 you cannot revert to a previous version, so you should back up data prior to upgrade or load PCM 3.0 on different hardware. Because of the variety of upgrade scenarios, upgrade information is provided in the PCM 3.0 installation.

Supported Software

- PCM Server
 - MS Windows 2003 Server Enterprise Edition SP2 (32-bit)
 - MS Windows XP Pro SP2 or SP3 (32-bit) *
 - * MS Windows XP Pro supports a maximum of 4Gb memory and 4 CPUs. Therefore, XP Pro cannot be used in some setups.
- Remote Client
 - MS Windows XP Pro SP2 or SP3 (32-bit)
 - MS Windows Vista Business/Ultimate (32-bit)
- Remote Agent
 - MS Windows XP Pro SP2 or SP3 (32-bit)
 - MS Windows 2003 Server (32-bit)
- IDM Agent
 - MS Internet Authentication Service (IAS) on MS Windows 2003 (32-bit)
 - MS Network Policy Server on Windows Server 2008 (32-bit)
 - RADIUS on the ProCurve Network Access Controller 800
 - Various Linux platforms

Minimum System Requirements

	<50	50-350	350-1200	1200-2400	2400-3500	Free Disk Space	NIC
Server	2 GB 1 CPU	2 GB 1 CPU	2 GB 1 CPU	2 GB 1 CPU	2 GB 1 CPU	60 GB	100/1000 MB
Remote Agent	2 GB 1 CPU	2 GB 1 CPU	2 GB 1 CPU	2 GB 1 CPU	2 GB 1 CPU	20 GB	100 MB
Remote Client (max 10)	2/4*GB 1 CPU	2/4*GB 1 CPU	2/4* GB 1 CPU	2/4*GB 1 CPU	2/4*GB 1 CPU	20 GB	100 MB
Min Agents (max 10)	1 local	1 local	1 local 3 remote	7 remote	10 remote		

* 4 GB RAM only for MS Windows Vista

CPU must be Xeon/Intel Pentium Core2 or equivalent CPU running at 3.0 GHz

One Agent can manage maximum of 350 devices

Recommended and VMWare system requirements are provided in the *PCM Installation and Getting Started Guide*.

HP ProCurve Manager Plus 3.0 Licensing

SKU	Description	Supported Devices	Agents
J9173A	Upgrade with 50-device licence plus one Agent license from previous HP PCM+ 2.x	50	1
J9174A	Entry level software with 50-device license plus 1 Agent license	50	1
J9175A	Incremental + 100-device license plus 1 Agent license	+100	+1
J9176A	Upgrade to unlimited device license with all support Agents from HP PCM+ 2.x unrestricted license	Up to 3500	10
J9177A	Software with unlimited device license and all supported Agents	Up to 3500	10



May, 2009

Part Number: 5992-5000



© 2009 Hewlett-Packard Development Company, LP. The information contained herein is subject to change without notice.